

Pusher Assembly

Problem Observed	Alarm / Tag	Possible Cause	Solutions
Matrix not pushed	CY6401	1: Cylinder not working	1: Check air supply or Reed Check
	PE6401 – Matrix Sensor	2: No matrix detected	1: Check sensor
Pusher plate not moving	CY6402	1: Cylinder issue	1: Check valve & air or Reed input